## **OCF Beauty Dishes Mounting instruction**



## About OCF Beauty Dishes

The OCF Beauty Dish is a collapsible and more portable version of the classic Profoto Softlight Reflector.

It creates a creamy yet crisp light, often referred to as a "beauty light." When it comes to bringing out the beauty of your subjects, it is second to none.

Since it is tailor-made for on-location photography, the OCF Beauty Dish is compact, lightweight and easy to

use. High-quality fabrics and patent-pending design allows you to snap it onto the speedring without having to bend and fumble with the rods.

Learn how to mount your OCF Beauty Dish fast and easy and how to combine it with a diffuser and/or OCF Gels in this quick guide.



Place the rod into the OCF Speedring.



Press the rod upwards until you hear a click, which means the rod is mounted fully into the OCF Speedring.



First mount only two rods fully into the speedring (see step 1 and 2), thereafter work yourself around the speedring by mounting the other six rods one by one half way (45 degree angle) into the speedring. Lastly, press the six rods upwards one by one until you hear a click.



4 Now all the rods are mounted correctly.



Tighten the beauty dish fabric with the Velcro to prevent light from leaking out. Stretch tight.



6 Mount the deflector plate by snapping on the four hooks one by one.

The deflector plate can stay mounted when the beauty dish is collapsed.



7 The OCF Beauty Dish is ready to be used.

## How to combine the OCF Beauty Dish with a diffuser



- Mount the diffuser on the OCF Beauty Dish by starting in one upper "corner". Then easily put it on the remaining corners.
- Now the diffuser is mounted correctly on the OCF Beauty Dish.

## How to combine the OCF Beauty Dish with the OCF Gels



- Mount the OCF Beauty Dish on your Off-Camera Flash, just as you would without the gel.
- Then insert your prepared OCF Gel Kit and mount it on your Off-Camera Flash.

Attention

This product may only be used with Profoto Off-Camera flashes that has a LED modeling light.

Follow the instructions to avoid jamming your fingers

For more information and inspiration:

profoto.com/offcameraflash